

[illegible]

0040112292	Front cover		√		√									
0040112293	Front panel		√		√									
0040112294	Right panel		√		√									
0040112295	Rear panel		√		√									
0040112296	Motor Bracket		√		√									
0040112312	Hanging wall panels	√				√						√		
0040112487A	Quick-insert clips	√				√						√		
0040112532	Fixing plate	√				√						√		
0040112534	Electric control box cover	√				√						√		
0040113023	Chassis										√			√
0040113024	Chassis		√		√			√		√				
0040113044	Inlet and outlet bracket							√		√		√		√
0040113045	Heat Exchanger Bracket							√		√		√		√
0040113046	Platen											√		√
0040113047	Electric control box cover											√		√
0040113048	Electric control box sheet Metal											√		√
0040113049	Partition											√		√
0040113052	Platen		√		√			√		√				
0040113053	Electric control box cover		√		√			√		√				
0040113055	Electric control box sheet Metal							√		√				
0040113056	Partition							√		√				
0040113093	Compressor Chassis							√		√		√		√
0040113098	Compressor Chassis		√		√									
0040113197	Electric control box sheet Metal	√				√						√		
0040113202	Pump clamps	√				√						√		
0040113203	Partition		√		√									
0040113204	Electric control box sheet Metal		√		√									
0040113206	Inlet and outlet bracket		√		√									
0040113207	Heat Exchanger Bracket		√		√									
0040113242	Front shell assembly	√				√						√		
0040201979A	Handle		√		√			√		√		√		√
0040203295A	Handle			√			√		√		√		√	
0040205893	Fan		√		√						√		√	
0040205894	Drainage elbow		√	√	√		√	√	√	√	√	√	√	√
0040205900	Fan			√			√		√					
0040206020	Rubber rings	√				√						√		

0040206547	Compressor soundproofing cotton									√			√	
0040206646	Clamp	√	√	√	√	√	√	√	√	√	√	√	√	√
0040206919	Pump foam			√			√		√		√		√	
0040206920	Terminal box cover			√			√		√		√		√	
0040206920A	Terminal box cover		√		√			√		√		√		√
0040207365	Grille									√			√	
0040207366	Grille			√			√		√					
0040207561	Grille										√			√
0040207562	Fan										√			√
0040207565	Grille						√		√					
0040207570	Spout cover	√				√						√		
0040207576	Water tray assembly	√				√						√		
0040207582	Grille		√		√									
0040207583	Fan						√		√					
0040207603	Fixed columns	√				√						√		
0040208029	Base	√				√						√		
0040208169	Display panel	√				√						√		
0040208379	Rubber mats	√				√						√		
0040300704	Rubber rings	√				√						√		
0040401467A	Ambient Temperature Sensor	√	√	√		√	√	√	√	√	√		√	√
0040401628B	Water pressure sensor	√				√						√		
0040401812	Low pressure switch		√	√	√		√	√	√	√	√		√	√
0040402518	Defrost temperature sensor	√	√	√		√	√	√	√	√	√		√	√
0040402518A	Coil temperature sensor	√		√			√		√		√			√
0040402616	Terminal Block	√	√	√	√		√		√		√		√	
0040402624	Terminal Block	√	√		√	√		√		√		√	√	√
0040402641	Auxiliary circuit inlet temperature	√	√	√		√	√	√	√	√	√		√	√
0040402642	Auxiliary circuit outlet temperature	√	√	√		√	√	√	√	√	√		√	√
0040402668C	Discharge Temperature Sensor	√	√	√		√	√	√	√	√	√		√	√
0040402671D	Suction Temperature Sensor	√	√	√		√	√	√	√	√	√		√	√
0040402710	Power terminal block					√		√		√		√	√	√
0040402741	Reactor		√	√	√		√		√		√		√	
0040402876A	Drive board						√		√		√			√
0040402899	Compressor heating strip						√	√	√	√	√		√	√
0040402999	Water outlet temperature sensor	√	√	√		√	√	√	√	√	√		√	√
0040403114	Electric Heater			√			√		√					

0040403141	Pump			√			√		√		√			√	
0040403198	Motor			√			√		√						
0040403324	Motor										√			√	
0040403326	Electric heating of pipes										√			√	
0040403337	Compressor heating strip	√	√	√			√		√						
0040403338	Water flow switch			√			√		√						
0040403339	Deicing electric heating belt	√	√	√			√	√	√	√	√	√		√	√
0040403352	Water flow switch										√			√	
0040403395	Water outlet 2 temperature sensor			√			√		√		√			√	
0040403397	Condensation temperature sensor	√	√	√			√	√	√	√	√	√		√	√
0040403410	Reactor		√	√	√		√	√	√	√	√	√		√	√
0040403411	High pressure switch			√			√		√		√			√	
0040403538	Reactor							√		√		√			√
0040403665	Manually reset the thermostat	√					√						√		
0040403666	Electric Heater	√					√								
0040403667	Electric Heater												√		
0040403668	Pump	√					√								
0040403669	Pump												√		
0040403670	Solenoid valves	√					√						√		
0040403732	Motor		√		√			√		√					
0040403733	Motor											√			√
0040511762	Packaging box			√			√		√						
0040511905	Packaging box										√			√	
0040513073	Cushions-1	√					√						√		
0040513189	Cushions-2	√					√						√		
0040513190	Cushions-3	√					√						√		
0040513191	Cushions-4	√					√						√		
0040513192	Cushions-5	√					√						√		
0040513193	Cushions-6	√					√						√		
0040513194	Cushions-7	√					√						√		
0040513195	Cushions-8	√					√						√		
0040513196	Cushions-9	√					√						√		
0040513198	Cushions-10	√					√						√		
0040700293	ELECTRIC EXPANSION VALVE ASSY.										√			√	
0040701054	Auxiliary circuit electronic expansion valve	√					√		√						
0040701731	Main circuit electronic expansion valve	√					√	√	√	√					

[illegible]

0040817977	Electric control box assembly					√								
0040818174	Electric control box assembly	√												
0040818175	Electric control box assembly			√										
0040818481	Safty Valve	√			√							√		
0040818900	Copper tube	√			√							√		
0040819093	Safty Valve		√		√			√			√			√
0040819553	Electric control box assembly	√												
0040819554	Electric control box assembly				√									
0040819555	Electric control box assembly											√		
0040819675	Electric control box assembly													√
0040819698	Electric control box assembly								√					
0040820429	Electric control box assembly						√							
0040820544	Electric control box assembly											√		
0041801478	Drive board							√			√			√
0041801478A	Drive board			√			√		√					
0041801506	Main control board										√			
0041801506A	Main control board			√			√		√					
0041801506B	Main control board						√							
0041801506C	Main control board								√					
0041801506D	Main control board												√	
0041801622	Main control board		√											
0041801622A	Main control board				√									
0041801622D	Main control board							√						
0041801622E	Main control board								√					
0041801622F	Main control board											√		
0041801622G	Main control board													√
0041801625	Main control board	√				√							√	
0041801638	Display board assembly	√				√							√	
0041801645	Drive board		√		√									
0150402224	14-bit terminal block			√			√		√			√		√
0150768688	Expansion Vessel	√				√							√	
0150768874	Refrigerant Separator		√		√			√		√		√		√